

S2.5 Wrench

S3 Wrench

S12 Wrench

(supplied)

(supplied)

(supplied)

Saw

المستعلما والمستعلما والمستعلما والمستعلما والمستعلما والمستعلما والمستعلما والمستعلما والمستعلما والمستعلم و

Ruler

S5 Wrench

(supplied)

Pencil

Philips

Level

Screwdriver

- 6. After installation, check all the joints to make sure they are firmly connected. Then keep water flow. Turn on and off repeatedly to ensure no leaking problem. After that, the product is ready for normal use.
- 7. Hand the manual to users.

II. Operation Notice

- The product is used under cold water temperature 4~29°C, hot water temperature 55~85°C and water pressure 0.05~1.0 MPa. To avoid large pressure difference between hot and cold water, the thermostatic cartridge is preferably in use under the condition of water pressure 0.3 MPa, cold water 15°C, hot water 65°C. Main valve should be equipped with a filter.
- 2. Do not hang heavy things on the mixer.
- Remember to turn off the mixer when no water comes out of it (especially when nobody in the house or during the decoration period or power off).
- 4. Clean the surface of mixer regularly to keep it bright. Note: Please do not use inappropriate tools such as sharp brushes, rough sponges, scouring pads or corrosive detergent. And it is not recommended to use the detergent sold in the market, because its formula changes frequently. Please clean the mixer with wet cloth and soapy water after some time of . usage. Then rinse the soap off with clean water and dry with a soft cotton
- cloth.
- 5. When indoor temperature drops below 0°C, take necessary measures (keep mixer warm, close windows) to prevent the mixer from frost cracking (especially when windows are kept open for ventilation while nobody in the house).
- Run cold water first and then run hot water, adjust the temperature before in use. Do not touch the hot water area of the mixer to avoid injury.
- 7. Do not disassemble the product without help from the professionals.







